Fundamentals of Laboratory Safety Near Miss Scenario

You enter a laboratory one morning and the flutter tape is blowing out indicating air is moving out of the laboratory. You know that directorial airflow should flow into the laboratory. What do you do?

Link to video job aid <u>Fundamentals of Laboratory Safety - Near Miss Scenario</u> OneLab REACH (cdc.gov)